

HOW TO ASSEMBLE FH3 FLOATING HIDE



**MAR
JAN
GEAR**

01

WARNING !

THE FIRST WE WISH TO REPEAT THE STANDARD GENERAL WARNINGS:

- A FLOATING HIDE IS NOT A BOAT IF YOU ARE NOT IN A GOOD CONDITION, DO NOT GO INTO THE WATER.
- DO NOT ENTER THE WATER IF YOU DO NOT KNOW WHERE YOU ARE GOING .
- WE ARE NOT RESPONSIBLE FOR YOUR GEAR WE RESERVE THE RIGHTS TO MODIFY THE PRODUCT AT ANY TIME

INCLUDE IN THE FH3 PACK

- 2 INFLATABLE TUBES
- 4 SUPPORTS
- 6 METAL TUBES
- A CAMERA PLATE
- 2 SCREWS AND 2 RINGS TO FIX YOUR CAMERA HEAD ON THE PLATE



02

USER GUIDE

NOW TO THE JOB :

1. FIRST OF ALL LAY OUT ALL COMPONENTS IN FRONT OF YOU SECONDLY INFLATE THE TUBES SLIGHTLY SO THEY GET THE ROUND SHAP. ON PICTURE YOU SEE 2 METAL TUBES INSERTED IN THE 2 SLEEVES ON EACH SIDE . TAKE CARE TO KEEP LEFT AND RIGHT TUBE-WITH THE TOP POSITION IN A CORRECT POSITION



THE METAL TUBES YOU INSERT IN THE SUPPORTS - BOTH SUPPORTS ARE FACING EACH OTHER WITH THE INSIDE TOWARDS EACH OTHER.

03

04

05

3. ALWAYS FIX THE BOTTOM METAL TUBE THROUGH THE BOTTOM SUPPORT - WHILE THE TOP METAL TUBE - YOU CAN SLIDE THROUGH THE TOP SUPPORT AND THE SLEEVE BUT SLIDING THROUGH THE SECOND SUPPORT IS AT THE END.

4. THE CAMERA PLATE - TAKE THE 2 TUBES WHICH HOLD THE CAMERA PLATE - POSITION THE CAMERA PLATE ON ONE SIDE OF THE METAL TUBES - SLIDE THE TUBES IN THE SUPPORTS - AND AFTERWARDS SLIDE THE CAMERA PLATE TOWARDS THE END WHERE YOU HAVE FIXED THE METAL TUBES IN THE SUPPORT - THIS ALLOWS YOU TO MOVE MORE FREELY THE TUBES AND FIX THEM ON THE OTHER SIDE IN THE SUPPORTS.



5. THE STRAPS KEEP YOUR CAMERA PLATE IN THE CENTER OF THE TUBES AND KEEP YOUR INFLATED TUBES FIXED TO THE FRAME .

06

WE SUPPLIED AN ANTI SPLASH WITH YOUR FLOATING HIDE - WHICH MUST BE MOUNTED BEFORE COMPLETE INFLATING THE TUBES - AS YOU CAN SEE ON THE ENCLOSED PICTURES .



7. THE TENT SUPPLIED WITH THE FH 3 IS EASY TO SET UP: INSERT THE POLES INTO THE SLEEVES: POSITION THE FOUR ENDS OF THE POLES IN THE BRACKETS ON THE SIDE OF THE INFLATED TUBES - THEN ATTACH THE TENT HOOKS TO THE D-RINGS.

8. THE TENT COMES WITH A VELCRO® POCKET THAT CAN BE USED TO HOLD A SPARE BATTERY OR OTHER ITEMS WHILE YOU ARE IN THE WATER.

9. THE CAMERA PLATE REQUIRES A SCREW HOLE TO ATTACH YOUR BALL HEAD - DEPENDING ON THE LENGTH OF YOUR LENS, YOU WILL NEED TO DRILL A 10MM HOLE FOR THE SCREW. IF NECESSARY, YOU CAN DRILL A SECOND OR THIRD HOLE IN THE CAMERA PLATE DEPENDING ON THE DIFFERENT LENSES YOU USE.

07

[WATCH TUTORIAL](#)

**FIND
OUR PRODUCTS**



**MR
JAN
GEAR**

WWW.MRJANGEAR.COM